



Disney

10780



WARNING: CHOKING HAZARD.
Toy contains small parts and a small ball.
Not for children under 3 years.



AVERTISSEMENT : RISQUE D'ÉTOUFFEMENT.


Le jouet contient des petites pièces ainsi qu'une petite boule.
Il ne convient pas aux enfants de moins de 3 ans.






ADVERTENCIA: PELIGRO DE ASFIXIA.



Juguete que contiene partes pequeñas y una pelota pequeña.
No recomendado para niños menores de 3 años.















































































































































































Disney



10776



10774



10772



10775



10773



Disney
MICKEY
AND FRIENDS





Disney

10778



10780



10777



4+

Disney
MICKEY
AND FRIENDS





Rebuild
the
world™



LEGO and the LEGO logo are trademarks of the/son des marques de commerce du/
son marcas registradas de LEGO Group. ©2022 The LEGO Group. 6418205

©Disney